



User Manual

AUREA III 5 NTP

AUREA III 5S NTP





Index

General	3
Functional description	3
Synchronisation	3
Safety	3
Installation	4
Configuration using R F P buttons	7
Configuration using a WEB browser	9
Firmware Download / Wunser	23
Technical specification	25
Abbreviations	26

General

AUREA III are Digital Clocks for indoor use, displaying time in hours and minutes. The time can be displayed in either 12- or 24-hour format. The clock can also be configured to show the time, date and temperature alternately. Light intensity of the digits is adjustable by an automatic dimmer control.

The clock is prepared for time synchronization by Network Time Protocol (NTP) from an NTP server. If the connection to the NTP server is lost the clock will continue to run on the built-in time base. Configuration of network settings, light intensity and other parameters is done via a WEB-browser.

The factory default setting for the IP address assignment is DHCP with fallback IP address 192.168.3.10. Please note, if default settings are used no configuration is needed.

The clock is powered by 230 V mains. In case of power failure, the display is turned off, but the built-in real-time clock will continue to run for 48 hours. When the power is restored it will resynchronize automatically.

Functional description

Start up

When the power cable is connected to the electronics, the clock will display the time from the internal timekeeper. If no correct time, the display will show lines.

After some seconds, the clock tries to receive a correct time message from an NTP server and then display correct time.

In case the NTP would disappear, the clock will run on built-in quartz crystal.

Synchronisation

NTP

The clock is prepared for time synchronization by Network Time Protocol (NTP) from an NTP server. When a correct time message is received the clock will display correct time automatically.

The colon between hours and minutes will flash when the clock is in sync and the time message is accepted.

Standalone

If the clock does not have an external synchronisation, it operates standalone.


Safety

Installation and maintenance of this device must be performed by accredited personnel.

This product must not be installed by unauthorized users/operators. Electrical installation of the equipment must comply with applicable electrical standards.


Installation

- Unscrew 4 screws, 2 pieces at each side.




- Remove the front and mount the back plate on the wall, using 4 screws suitable for the wall. We recommend $\text{Ø}4\text{mm}$ and 30mm long screws.

AUREA III with second




AUREA III without second




Connection

- The connections are made on the inside of the back plate. Unscrew the cover and put aside without damaging the wire.
- Connect the LAN cable to RJ45.
- Disconnect power before hard installation. The cable must be double-insulated and stripped to a maximum of 3 cm. It must also be secured with the cable relief.
- Connect the power 230VAC, 50Hz.
When the clock is permanently installed a readily accessible disconnect device shall be incorporated in the fixed wires (2-polar, 3mm contact gap).
- Screw back the inner cover
- Reassemble the front



Temperature sensor, temperature/humidity sensor or external dimmer (Option)

If a temperature sensor is used, connect it to the CPU board according to the pictures below.




1. Red
2. Black
3. Shield

Configuration using R F P buttons

General

Configuration of network settings, light intensity and other parameters is done via a WEB-browser. Some of the parameters can also be set using three buttons located at one side of the clock. Please note, if default settings are used no configuration is needed.

The programming is made with push buttons placed on the side of the clock (see below).



Button

[R] Return Enter base mode (display time)

[F] Function Next function / Accept displayed value

[P] Program Enter the displayed function / Increase displayed value. Hold button for rapid count.

Programming time

1. Push [F] until display shows

ti nE

2. Push [P] and display shows

yy 13 (year)

3. Push [P] until desired year (00-99) and accept with [F]

4. Display shows

nn 1 (month)

5. Push [P] until desired month (1-12) and accept with [F]

6. Display shows

dd 1 (day)

7. Push [P] until desired date (1-31) and accept with [F]

8. Display shows

hh 12 (hour)

9. Push [P] until desired hour (0-23) and accept with [F]

10. Display shows

nn 07 (minutes)

11. Push [P] until desired minute (00-59), accept with [F] and clock starts

12. Display shows
13. Push [R]. Program finished
14. Display shows the set time

ti nE

Setting light intensity

The light intensity for the digits can be adjusted in 8 levels. An automatic dimmer function regulates the light intensity within each level.

1. Push [F] until display shows
2. Push [P] to select
3. Display shows
4. Push [P] until desired intensity (1 – low, 8 - high) and accept with [F]
5. Push [R]. Program finished

di SP

(display)

di 1

(display intensity)

View / configure IP address

The Clocks IP address can be either static or dynamic (DHCP). Configuration of IP addressing work mode is done using a web-browser. The default setting is DHCP.

Using the R F & P buttons it is possible to view or change the current IP-address. It is also possible to see if the Clock is using static or dynamic IP address.

If the work mode is DHCP it is not possible to change the IP address manually.

To view the current IP address:

In this example we demonstrate IP address 192.168.2.51

1. Push [F] until display shows
IP mode d = dynamic (DHCP), s = static IP
2. Push [P] to select
3. Display shows
4. Push [P] to select
5. Display shows
6. Push [P] to select
7. Display shows
8. Push [P] to select
9. Display shows
10. Push [R]. Return to base mode

IP d

(IP mode)

A1 92

(first part)

b1 68

(second part)

C 2

(third part)


d 51

(fourth part)

Configuration using a WEB browser

Login

It is possible to login as administrator or guest. The administrator has the rights to read and to write/change configuration. A guest can read only.

A screenshot of a login dialog box. The window has a blue title bar with a question mark icon and a close button. The main area has a light green background with a blue header bar containing a key icon. Below the header, there are two input fields: 'User name:' with a dropdown menu showing a user icon, and 'Password:' with a text box. Below the password field is a checkbox labeled 'Remember my password'. At the bottom, there are 'OK' and 'Cancel' buttons.

Username


admin or guest.

Password

Enter a password. Default password is *password*.
After the login a function menu will be shown.



Status



Westerstrand Urfabrik AB

Status Network NTP Clock General **Advanced**

Name	Clock_Name	Refresh
UTC	2020-01-24 09:43:54, week 4 Fri	
LT	2020-01-24 10:43:54, week 4 Fri	
Timezone	UTC+01:00, winter (CET)	
IP	192.168.2.23 (DHCP)	
Netmask	255.255.240.0	
Gateway	192.168.1.1	
DNS	192.168.1.13	
MAC	00-07-09-10-1E-D1	
Alarms	No alarms	
NTP	Synchronized: (172.16.0.70), s=2, n=132, TO=59 m	
Sensor	Dimmer=4/5, Sensor=10905, Temp=22 °C	
Uptime	0 day, 21 h, 51 min, 22 sec // Total: 78682 sec	
Firmware	LISA-Q162 (Jan 20 2020). BOOTK64-X150	

© 2020 Westerstrand Urfabrik AB

Name	Symbolic name. The name is set in function <i>General</i>
UTC/LT	Current time
Timezone	Offset to UTC during normal time (=winter time).
IP	The Clocks IP address
Netmask	Shows the netmask setting
Gateway	Shows the IP address of the gateway
DNS	Shows the IP address of the DNS server
MAC	A MAC address has format 00-07-09-xx-xx-xx



Alarms	Shows if the Clocks has any alarms. The following alarm texts can be displayed. <i>No Alarms</i> = Clock OK. <i>Not synchronised</i> = The Clock is not synchronised. <i>5-minute limit</i> = The received time message is more than 5 minutes wrong compared to internal time. The message is not accepted. <i>Authentication</i> = The MD5 authentication has failed. <i>Temp is out of bounds</i> = Temperature reading is currently out of bounds.
NTP	Synchronised = The clock has been synchronised from an NTP server with name/IP ntp.se s = Stratum, time quality. A low value is better. n = Number of time settings from this NTP server. TO = Timeout in minutes before NTP alarm.
Sensor	Dimmer=4/5: Current dimmer value / Set dimmer level. Maximum value 8. Sensor=8784: Current light sensor data. Possible values 0-65535. Temp=21° C: Current temperature reading.
Uptime	Time in operation since last power failure.
Firmware	Present firmware version.



Network

Enter general network parameters.

The screenshot shows the 'Network' configuration page for Westerstrand Urfabrik AB. The page has a navigation bar with tabs for Status, Network (selected), NTP, Clock, General, and Advanced. The configuration is organized into sections: DHCP, Static IP, Utilities, and SNMP. The DHCP section has 'Use DHCP' selected and a 'Fallback' IP of 192.168.3.10. The Static IP section has 'Use static IP' unselected and empty fields for Address, Subnetmask, Gateway, DNS 1, and DNS 2. The Utilities section has 'Syslog' unselected, 'Identity access' set to 'Normal', and 'Telnet', 'HTTP', and 'HTTPS' unselected. The SNMP section has 'Enabled' checked, 'Read community' set to 'public', 'Read/write community' set to 'private', and empty fields for Trap address 1, 2, and 3. The 'Trap type' is set to 'v2'. A 'Save' button is at the bottom right.

Westerstrand Urfabrik AB

Status Network NTP Clock General Advanced

DHCP

Use DHCP

Fallback

Static IP

Use static IP

Address

Subnetmask

Gateway

DNS 1

DNS 2

Utilities

Syslog

Identity access ▼

Telnet

HTTP

HTTPS

SNMP

Enabled

Read community

Read/write community

Trap address 1

Trap address 2

Trap address 3

Trap type v1 v2

Save

© 2020 Westerstrand Urfabrik AB



DHCP

Off – Static IP address according to static IP below.

On – DHCP IP address with fallback according to IP fallback below.

Fallback: If DHCP is activated this will be the DHCP fallback address.

Static IP

To be checked if static IP address is used.

Address: Enter the static IP-address.

Subnetmask: Enter the subnetmask.

Gateway: Gateway IP address.

DNS: IP address of DNS server. Two different addresses can be entered, DNS1 and DNS 2.

Utilities

Syslog: Syslog server IP address. Send syslog messages if checked.

Identity access: Identify access is used in combination with application software Wunser. Wunser is a PC program that is used for finding and doing light configuration on Westerstrand Ethernet products. Firmware updates are also handled by Wunser.

Wunser uses UDP port 9999 when communicating with other Westerstrand products and UDP port 69 when downloading new firmware. These ports can be open, closed or prepared for encrypted communication.

Identify access = Normal ; port 9999 and port 69 is open.

Identify access = Password ; port 9999 and port 69 are using AES encryption. The password used is the same as the administrator login password.

Identify access = Disabled ; port 9999 and port 69 is closed.

Telnet: Use of Telnet protocol allowed if checked.

Web server: Use of HTTP protocol (web-browser) allowed if checked.

HTTPS: Use of secure communication protocol HTTPS (web-browser) if checked.

SNMP

This function is used to activate the SNMP, enter the address of one or more SNMP servers and to define the SNMP community. The IP address can be specified as an IP address or as a full domain name. Up to three SNMP server addresses can be entered.

Trap type: This function is used to choose SNMP trap version.

Trap type v1 = Trap according to SNMPv1

Trap type v2 = Trap according to SNMPv2

NTP

NTP settings

General Description

Westerstrand NTP Clients has several features to achieve a reliable and accurate time. The configuration of the different facilities is flexible, and the features can be selected or deselected depending on each customer's individual needs.

As an NTP Client the unit has three different ways to determine the most accurate and reliable candidates to synchronize the system clock. Which model that is used depends on the specific installation and the customer requirements. The NTP client has also a server list where up to 5 different time servers can be entered.

The three different ways are:

1. FIRST Always use the first server in the list if available. If not available, take the next one.

This suits installations where it is more important to know exactly from where the clients get time than to have the most accurate time. The other NTP servers in the list will then be more of backup servers.

2. STRATUM Use the NTP server with best stratum. The software sends a request to all servers in the list and uses the time from the one with best stratum. If same stratum it will use the one that is first in the server list.

This suits installations where it is important that the time is coming from a time server high up in the pyramid.

3. MEDIAN Send a request to all servers in the list and use the median value (the NTP server that is in the middle). This will filter out all misleading time messages.

In addition to these rules there are some more features such as synchronization limits and a clock discipline algorithm is also included. This algorithm measures the oscillators drift over a longer period and makes compensations for the drift.



Westerstrand Urfabrik AB

Status Network **NTP** Clock General **Advanced**

DHCP option 42

Broadcast

Multicast

NTP 1

NTP 2

NTP 3

NTP 4

NTP 5

Set Local Time

Local Time

Interval minutes

Remove time at alarm

Alarm timeout minutes

Timezone

Daylight Saving Time

NTP Advanced

© 2020 Westerstrand Urfabrik AB

DHCP option 042

Ask for time using the server IP addresses received from the DHCP server (DHCP option 0042).
Maximum 2 NTP servers are set automatically by option 0042.

Broadcast

Accept broadcast/multicast time messages. Broadcast address: 255.255.255.255

Multicast

Accept multicast time messages. Multicast address: 224.0.1.1



NTP server

Select NTP servers, e.g. *192.168.1.237* or as an URL *ntp.se*. Also see **NTP mode=DHCP** above

Up to five different NTP servers can be entered. If the first one fails it will automatically go to the next one and so on.

Set local Time

Used for manual time setting.

Interval

Interval in seconds between NTP requests.

Remove time at alarm

This function is used to define how the clock should behave during a NTP synchronization alarm. See Alarm timeout below. If the checkbox is checked the clock will show --:-- in case of synchronization alarm. If the box is not checked, the clock continues to show time and uses its own built-in quartz oscillator as time reference.

Alarm timeout

Time in minutes before the NTP synchronization alarm is activated.

Timezone

Select country/time zone. A NTP server sends UTC time. The clock will correct this to local time. If Daylight Saving Time (see below) is checked it will also and adjust for DST (Daylight Saving Time) automatically.

Daylight Saving Time

If checked then this timezone uses DST (Daylight Saving Time).

NTP advanced

Advanced NTP settings

Status	Network	NTP	Clock	General	Advanced
Client Mode	First ▼				
5 minute limit	<input type="checkbox"/>				
Only accept Stratum 1	<input type="checkbox"/>				
Authentication	<input type="checkbox"/>				
Server 1 ID	0	Key			
Server 2 ID	0	Key			
Server 3 ID	0	Key			
Server 4 ID	0	Key			
Server 5 ID	0	Key			
<input type="button" value="Save"/>					

© 2020 Westerstrand Urfabrik AB

Client mode

FIRST. Always use the first server in the list if available. If not available take next one.

This suits installations where it is more important to know exactly from where the clients get time than to have the most accurate time. The other NTP servers in the list will then be more of backup servers.

STRATUM. Use the NTP server with best stratum. The software sends a request to all servers in the list and uses the time from the one with best stratum. If same stratum it will use the one that is first in the server list.

This suits installations where it is important that the time is coming from a time server high up in the pyramid.

MEDIAN. Send a request to all servers in the list and use the median value (the NTP server that is in the middle). This will filter out all misleading time messages.

Only accept Stratum 1

This function makes it possible to synchronise to Stratum 1 time servers only.

Check box = Off ; synchronise to time server independent of stratum level.

Check box = On ; synchronise only if time server is operating on Stratum 1 level.

Authentication

If authentication is activated: Use MD5 authentication.

Server ID/Key: Authentication data for the external NTP servers configured in the NTP server list.



Clock

Used to configure general clock parameters.

Westerstrand Urfabrik AB

Status Network NTP **Clock** General Advanced

Name	Clock_Name
Leading zero	<input type="checkbox"/>
12h clock	<input type="checkbox"/>
Show Time	<input type="text" value="6"/> seconds
Show Date	<input type="text" value="0"/> seconds
Show Humidity	<input type="text" value="0"/> seconds
Show Temp	<input type="text" value="0"/> seconds
Temp Offset	<input type="text" value="0"/> (-9..+9 °C)
Temp Alarm	
Min	<input type="text" value="-20"/>
Max	<input type="text" value="55"/>
Dimmer	<input type="text" value="5"/>
Light sensor	<input checked="" type="checkbox"/>
Disable buttons	<input type="checkbox"/>
Remove alarms	<input type="checkbox"/>

© 2023 Westerstrand Urfabrik AB

Leading zero

Time: not checked; " 8:29",checked; "08:29".

Date: not checked; " 7.9 ", checked "07.9 " (Sep 7).

12h clock

Show e.g. " 2:49" (12h clock) instead of "14.29" (24h clock).

Show Time

Loop-time in seconds for time.

Show Date

Loop-time in seconds for date.



Show Humidity

Loop-time in seconds for relative humidity.

Show Temp

Loop-time in seconds for temperature.

Temp Offset

Adjust the temperature reading (-9 to +9 °C).

Alarm

Set temperature bounds. The temperature alarm "Temp is out of bounds" will be active when the temperature reading is below the min value, or above the max value.

Dimmer

Enter the dimmer value (1-8).

Light sensor

Allow for input from light sensor.

Disable buttons

Disable buttons on the clock. When the buttons are locked the only thing that can be done using the buttons is to read the IP-address.



General

Used to configure general parameters.

The screenshot shows the 'General' configuration page for Westerstrand Urfabrik AB. The page has a navigation bar with tabs: Status, Network, NTP, Clock, General (selected), and Advanced. The main content area is divided into sections:

- Name:** A text input field containing 'Clock_Name'.
- Contact:** An empty text input field.
- Location:** An empty text input field.
- Password:** Two rows of password fields. The first row is for 'admin' with a 'Repeat' field. The second row is for 'guest' with a 'Repeat' field. All password fields contain two dots (••).
- Miscellaneous:** A section containing:
 - Firmware:** A text field with the value 'LISA-Q162 (Jan 20 2020). BOOTK64-X150'.
 - Firmware Download:** A checkbox that is currently unchecked.
 - Restart Program:** A checkbox that is currently unchecked.
- Backup/Restore:** A section containing:
 - Filename:** A text input field with 'Clock_Name.txt'.
 - Backup:** A button.
 - Restore:** A button.
 - Program restarts!** A text label.
 - A 'Välj fil' button and the text 'Ingen fil har valts' are also present.

A 'Save' button is located at the bottom right of the main configuration area. The footer of the page reads '© 2020 Westerstrand Urfabrik AB'.

Name

Symbolic name, maximum 64 characters. This name is shown in the status menu and is also included in SNMP and Syslog messages. Example: Digital Clock, reception.

Contact

Contact person. This information is included in SNMP messages.

Location

The place where the clock is located. Example: "Building 3 Room 214". This information is included in SNMP messages.

Password

Login password.

Admin = Administrator password. The administrator has the rights to read and to write/change configuration. Default password = *password*.

To switch off the password functionality enter password = *nopassword*

Guest = Guest password. A guest can read only. The button [Save] is deactivated for guest users.

Default password = *password*.

Firmware Download

Function to enable firmware download. See also section *Firmware Download*.

Restart

Restart the Clock.


Backup/Restore

Backup

Save the clock configuration to a file. The clock suggests the Name field as filename (here *MyLanur229.txt*).

Click [Backup].

Passwords are not saved.



Backup/Restore

Filename:

Ingen fil har valts Program restarts!


Restore

Select file ([Välj fil]). Here file *myLanur229.txt* was selected.

Click [Restore].

The clock restarts. Refresh the page.

The MAC- and IP-address never are restored.




Backup/Restore

Filename:

Lanur_JE3.txt Program restarts!

Advanced

Functionality to configure hardware settings for the clock, and to do a factory reset of the clock. Changing the hardware settings may cause the clock to function improperly.



WESTERSTRAND
W
Sweden

Westerstrand Urfabrik AB

Status Network NTP Clock General **Advanced**

Important: Change here may cause the product to not work properly.

Name Clock_Name

Displaytype 8bit

With Second

Double blink

Sensortype None

Factory reset

Save

© 2023 Westerstrand Urfabrik AB

Display type

Set type of display.

With Second

Set whether the clock has second digits.

Double blink

When checked, and the clock is synchronised, the colon between minutes and seconds is flashing, otherwise it is steady. The first colon (between hours and minutes) is always flashing.

Sensortype

Select the type of sensor.

None: no sensor connected

DS1820S: Temperature sensor DS1820S

AM2302: Humidity and temperature sensor AM2302.

External Dimmer: External dimmer adjusts the light intensity in the display using a rheostat.

Factory Reset

Reset the clock to factory settings.



Firmware Download / Wunser

General

The Clock has support for firmware upgrade via the network. The utility program Wunser is used for firmware upgrade. Wunser can be downloaded using the following link:

<http://www.westerstrand.com/archives/download.htm>

If checkbox Firmware Download is clicked, then the application jumps to a boot-loader. If no firmware upgrade take place within 60 seconds, then the old application is restarted again with the current firmware. *When the clock is in boot-loader mode, then the green LED on the RJ45-connector is flashing.*

When the program is in boot-loader mode, then the clock will answer on PING only.

For details of the download procedure, see Wunser manual, 4296.

Also other programs, e.g. windows built in client tftp, can be used:

```
c:\ARM\Lisa>tftp 192.168.2.61 put LISA-Q132.MOT
```

```
Successful transfer: 1234092 byte 15 sec., 82272 byte/s
```

Find IP-address


At delivery, the clock is set to DHCP, with fallback address 192.168.3.10. If this has been changed and is unknown, the clock can be found using Wunser, see manual 4296. The clock is identified in the product list by its MAC-address. Each product is labelled with the individual MAC-address.

Reset Button

At a normal start (Reset Button is not pressed) then the green LED is flashing about 2 seconds. Then the green LED is turned off. When the clock is synchronized the green LED is turned on.

Action when the Reset Button is pressed:

Power up	The application stays in boot-loader mode for ever and waits for firmware upgrade.
Application 3-9 seconds	Soft reset. The application restarts immediately.
Application ≥ 10 seconds	Cold reset. The application restarts immediately in DHCP mode. If no DHCP server exist, the clock will take default address 192.168.3.10 after 60 seconds. All parameters except the MAC address will take default values.





Technical specification

General

Art. no.:	AUREA III - series
Mounting/Installation:	Single sided Wall.
Digits:	Single line red LED. Indicating time in HH:MM or HH:MM:SS
Digit height:	50 mm
Synchronisation:	NTP
Accuracy	0,1 sec/24 h at 22° C (free-running mode)
Internal time keeping during power failure:	48 hours (display is turned off)
Time format:	12- or 24-hour format selectable. Alternatively showing date: day and month.

Network

Protocols supported:	SNTPv4, RFC 4330, SNMP v2c, MIB II (RFC 1213), RFC2863, HTTP, HTTPS, Telnet, FTP
NTP protocol modes:	Unicast client mode (point to point), support for DHCP option 042, Broadcast/Multicast mode (point to multipoint). Multicast group address 224.0.1.1
Transport protocol:	TCP/IP
IP address assignment:	Static IP address or Dynamic (DHCP)
Compatibility:	Ethernet version 2/IEEE 802.3
Ethernet:	Supports 10/100BASE-T (RJ45) connections
Ethernet cable type:	Shielded
Device Management:	Web-Based (requires web browser) or via Telnet
Additional info.:	Support for DNS

Power supply

Supply voltage:	100-240VAC 50/60Hz
Power consumption:	0,35A

Environmental

Temperature range:	0°C to +40°C.
IP class:	IP 30

Housing

Housing:	Aluminium
----------	-----------



Abbreviations

DST	Daylight Saving Time
DHCP	Dynamic Host Configuration Protocol
DNS	Domain Name System. The Internet's system for converting alphabetic names into numeric IP addresses.
LED	Light Emitting Diode
LT	Local time
MAC	Physical address (Media Access Control)
NTP	Network Time Protocol
PING	Packet Internet Grouper
SNMP	Simple Network Management Protocol
UTC	Coordinated Universal Time