TAn



User Manual Time Log

119621-00

### General

Battery-operated time aid for indoor use in dry environments. The delivery includes stickers in colours corresponding to the start buttons. The coloured stickers may be used to mark activity signs or schedules. For example, if an activity is to last for 30 minutes, it is marked with a green sticker.


#### Function

Countdown of time from 60, 45, 30 or 15 minutes. The LED bar shows the countdown.

Number of lit LEDs at start 12 LEDs for 60 minutes

9 LEDs for 45 minutes6 LEDs for 30 minutes3 LEDs for 15 minutes

One LED is going out every fifth minute until all LEDs have gone out. At the end of the counting period all LEDs are flashing, and a signal will sound 5 times to indicate that the selected time has run out. During signalling, the sound can be stopped by pressing one of the buttons.




## How to use

Press the button for the requested time. The corresponding number of LEDs will light up and countdown starts. The ongoing counting period may be cancelled by pressing the red and blue start button simultaneously for two seconds. Thereafter a new counting period can be started. The sound signal may be changed with the control on the short side of the time log. With the control in min-position, the sound is completely turned off and signalling is made by flashing LEDs only.

Locking screw

#### Battery

The delivery includes two 1,5 V batteries size R6. These last for approximately 60 hours of use. When the light intensity of the LEDs wears off both batteries are to be replaced. In order to install or replace batteries, the battery compartment must be opened using a screwdriver (Phillips no.1). Rechargeable batteries type NiMH, size R6 can also be used. (NiMH batteries and charger are however not supplied by Westerstrand.)



Dimensions 111x52x27 mm Weight 115 g

# Cleaning / Maintenance / Test volume

Wipe the time log with a damp, lint free rag with common cleaner or use a cleaning cloth specifically for electronics. Change batteries as needed. If necessary, a new front decal can be pasted on to the time log. To test the volume level of the sound signal, press the two middle buttons simultaneously. The test function is turned off by pressing a button.

#### Option

119607-00 Key chain 119608-00 Protection case